


1/2" Diameter Winding Bar



Door Spring

Retainer Ring

Bracket Plate

Paw Spring



Scale: None

Part Number: U160005

Manufactured

Date: 04-02-04

Ratchet Tension Device Installation

By: CDW

Sheet: 1 of 2


Checked By: DL

Sheet Size: A

Drawing Number: U160005

Rev. 0

Caution: Before Adjusting spring Tension be
Sure Door is in Open Position.



To add more tension on spring
pull down on winding bar



1/2" round steel bar 12" long

To lessen spring tension, first release
ratchet pawl by pulling downward
on the winding bar at same time you
pull downward on ratchet pawl.
Then allow winding bar to go in
upward direction 1/4 turn.

Ratchet Pawl



Scale: None

Part Number: U160005

Manufactured

Date: 04-02-04

Ratchet Tension Device Installation

By: CDW

Sheet: 2 of 2

Checked By: DL

Sheet Size: A

Drawing Number: U160005

Rev. 0